



Radiant Glow Cream Highlighter

Formulation Reference: FM00249/C

Get natural looking radiance with this lightweight cream highlighter which will help enhance your features with a subtle sheen. Texiterra cold pressed oils of **Kalahari Melon Seed** and **Marula** help hydrate and nourish whilst melting into the skin. Natural emollient **Texique Lux5** aids spreadability, with **Texique HE50** as the main emulsifier and thickener.

Use alone on top of make-up for an all-over subtle glow or apply lightly to cheekbones, eyelids, bridge of nose, brow bone and bow of lips for an added natural glow.

Phase	Ingredients	Function	% w/w	Trade Name
A	Aqua	Solvent	Up to 100%	Deionised Water
	Disodium EDTA	Chelating Agent	0.05	Dissolvine NA2 ¹
	Citric Acid Monohydrate	pH Adjuster	0.03	Citric Acid Monohydrate ²
	Polysorbate 20	Surfactant/ Solubiliser	1.00	Tego SML 20 MB ³
B	Citrillus Lanatus (Watermelon Seed) Oil	Oil/ Moisturising	2.00	Texiterra Kalahari Melon Seed Oil ⁴
	Sclerocarya Birrea Seed Oil	Oil/ Moisturising	1.00	Texiterra Marula Oil ⁴
	C13-15 Alkane (and) Caprylic/Capric Triglyceride	Emollient	1.50	Texique Lux5 ⁴
	Hydrogenated Polyisobutene	Emollient/ Dispersing Agent	3.00	Sophim MC 300 ⁵
	Phenoxyethanol	Preservative	1.00	Phenoxyethanol ⁶
C	Silicon Dioxide	Oil Absorber/ Light Diffuser	1.00	Silica Microspheres ⁷
D	Sodium Acrylates Copolymer (and) Lecithin	Gelling Agent/ Emulsifier	2.00	Lecigel ⁸
E	Acrylates/acrylamide copolymer (and) C13-15 Alkane (and) Trideceth-7	Thickener/ Emulsifier/Rheology Modifier	3.50	Texique HE50 ⁴
F	Glycerin	Humectant	4.00	Pricerine 9091 ⁹
	CI 77491, Mica	Pearl	0.82	Just Bronze 20C ¹⁰
	CI 77491, Mica	Pearl	0.60	Satin Bronze 20A ¹⁰



	CI 77891, Mica	Pearl	4.58	Timiron Super Gold 117217 ¹¹
--	----------------	-------	------	--

Suppliers: ¹ Nouryon | ² Univar | ³ Evonik | ⁴ **Scott Bader** | ⁵ Sophim | ⁶ Mystic Moments | ⁷ Micamoma | ⁸ Lucas Meyer Cosmetics | ⁹ Croda |
| ¹⁰ The Soap Kitchen | ¹¹ Merck |



Preparation procedure

1. Add Phase A materials to Deionised Water individually, mixing between additions until completely dissolved.
2. In a separate vessel combine Phase B and then sprinkle in Phase C using a sieve. Mix until smooth uniform.
3. Sprinkle Phase D into stage 2 pre-mix and mix until dispersed.
4. Add stage 3 pre-mix into Phase A and homogenise until smooth and uniform.
5. Add Phase E to main batch and mix until smooth and uniform.
6. Pre-mix Phase F until uniform. Add into main batch and mix until combined and uniform.

The information in this publication is based on laboratory testing and is believed to be accurate and is given in good faith, but no representation or warranty as to its completeness or accuracy is made. Suggestions for uses or applications are only opinions and are not intended for design purposes. Users are responsible for determining the suitability of these products for their own particular purpose and assume all risk and liability whether used singly or in combination with other materials. No representation or warranty, expressed or implied, is made with respect to information or products including, without limitation, warranties of merchantability, fitness for a particular purpose, non-infringement of any third party patent or other intellectual property rights.