





Anti-Acne Cream

Formulation Reference: FM00252/A

Help keep skin clear with this light, gentle cream for acne prone skin. Containing active Salicylic acid and Allantoin for soothing comfort. With *Texique HE50* as the sole emulsifier and thickener, this cold process formulation also contains light natural emollient *Texique Lux5*, in combination with *Texiterra Grapeseed Oil* and *Texiterra Kalahari Melon Seed Oil*, which help provide essential skin nourishment.

Phase	Ingredients	Function	% w/w	Trade Name
А	Aqua	Solvent	Up to 100%	Deionised Water
	Disodium EDTA	Chelating Agent	0.05	Dissolvine NA2 ¹
	Sodium Benzoate	Preservative	0.40	Sodium Benzoate Granular ²
В	Glycerin	Humectant	2.00	Naissance Vegetable Glycerine No 806 ³
	Butylene Glycol	Humectant	1.50	Activanol- BG (UK) Natural 4
	Acrylates/acrylamide copolymer (and) C13-15 Alkane (and) Trideceth-7	Thickener/ Emulsifier	5.00	Texique HE50 ⁵
С	C13-15 Alkane (and) Caprylic/Capric Triglyceride	Emollient	2.50	Texique Lux 5 ⁵
	Vitis Vinifera Seed Oil	Emollient/ Moisturising	2.50	Texiterra Grapeseed Oil ⁵
	Citrillus Ianatus (Watermelon Seed) Oil	Emollient/ Moisturising	2.50	Texiterra Kalahari Melon Seed Oil ⁵
	PEG-40 Hydrogenated Castor Oil	Solubiliser/ Cleansing Agent	0.50	Eumulgin CO 40 ⁶
D	Aqua	Solvent	5.00	Deionised Water
	Allantoin	Active Ingredient	0.50	Allantoin ⁷
Е	Aqua	Solvent	5.00	Deionised Water
	Panthenol	Active Ingredient	0.50	Lancos SC PAN ²







F	Phenoxyethanol	Preservative	0.60	Phenoxyethanol ⁸
	Cocamidopropyl Dimethylamine (and) Salicylic Acid	Active Ingredient	1.00	Curcylic 40 ⁹
	Parfum	Fragrance	QS	

Suppliers: ¹ Nouryon | ² OQEMA | ³ Naissance | ⁴ Activon Co Ltd | ⁵ **Scott Bader** | ⁶ BASF | ⁷ DSM | ⁸ Mystic Moments | | ⁹ Vantage Personal Care |

Preparation procedure

- 1. Weigh out Deionised water into the main vessel and add Phase A materials individually, with mixing between additions until completely dissolved.
- 2. Add Phase B and homogenise until smooth and uniform.
- 3. Add Phase C to the main batch one at a time with mixing between additions and homogenise until uniform.
- 4. In a separate vessel pre-mix Phase D and add to the main batch. Mix until smooth and uniform.
- 5. In a separate vessel pre-mix Phase E and add to the main batch. Mix until smooth and uniform.
- 6. Add Phase F to the main batch individually with mixing between additions. Mix until smooth and uniform.
- 7. Adjust to pH 5.0 6.0 using Citric acid if required.

The information in this publication is based on laboratory testing and is believed to be accurate and is given in good faith, but no representation or warranty as to its completeness or accuracy is made. Suggestions for uses or applications are only opinions and are not intended for design purposes. Users are responsible for determining the suitability of these products for their own particular purpose and assume all risk and liability whether used singly or in combination with other materials. No representation or warranty, expressed or implied, is made with respect to information or products including, without limitation, warranties of merchantability, fitness for a particular purpose, non-infringement of any third party patent or other intellectual property rights.

